

E



Unison, Praecis Cntp, and Tycho:

To check the leap second settings use the network port command **cdmaleapmode**. If in “user” mode, then

